



[www.alfatronelectronics.com](http://www.alfatronelectronics.com)  
ALFATRON ELECTRONICS GmbH GERMANY

ALF-IP6

## Wallplate Control Panel- 6 buttons



**All Rights Reserved**

Version: ALF-IP6\_2021V1.1

## **Preface**

Read this user manual carefully before using the product. Pictures are shown in this manual for reference only, different models and specifications are subject to real product.

This manual is only for operation instruction, please contact the local distributor for maintenance assistance. The functions described in this version were updated January 2018. In the constant effort to improve the product, we reserve the right to make functions or parameters changes without notice or obligation. Please refer to the dealers for the latest details.

## **FCC Statement**

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. It has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation.

Operation of this equipment in a residential area is likely to cause interference, in which case the user at their own expense will be required to take whatever measures may be necessary to correct the interference.

Any changes or modifications not expressly approved by the manufacture would void the user's authority to operate the equipment.

## SAFETY PRECAUTIONS

To ensure the best from this product, please read all instructions carefully before using the device. Save this manual for further reference.

- Unpack the equipment carefully and save the original box and packing material for possible future shipment.
- Follow basic safety precautions to reduce the risk of fire, electrical shock, and injury to persons.
- Do not dismantle the housing or modify the module. It may result in electrical shock or burn.
- Using supplies or parts not meeting the products' specifications may cause damage, deterioration, or malfunction.
- Refer all servicing to qualified service personnel.
- To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Do not put any heavy items on the extension cable in case of extrusion.
- Do not remove the housing of the device as opening or removing housing may expose you to dangerous voltage or other hazards.
- Install the device in a place with fine ventilation to avoid damage caused by overheat.
- Keep the module away from liquids.
- Spillage into the housing may result in fire, electrical shock, or equipment damage. If an object or liquid falls or spills onto the housing, unplug the module immediately.
- Do not twist or forcefully pull the ends of the optical cable. It can cause malfunction.
- Do not use liquid or aerosol cleaners to clean this unit. Always unplug the power to the device before cleaning.
- Unplug the power cord when left unused for a long period of time.
- Information on disposal for scrapped devices: do not burn or mix with general household waste, please treat as normal electrical waste.

## **Contents**

|  |    |
|--|----|
| 1. Introduction .....                  | 1  |
| 1.1 Introduction to ALF-IP6 .....      | 1  |
| 1.2 Features .....                     | 1  |
| 1.3 Package List .....                 | 1  |
| 2. Panel Description.....              | 1  |
| 3. System Connection.....              | 3  |
| 4. Control Panel Software.....         | 4  |
| 4.1 Basic Setting.....                 | 4  |
| 4.2 Panel Set .....                    | 7  |
| 4.3 Action List .....                  | 8  |
| 4.4 Event setting.....                 | 9  |
| 4.4.1 RS232 Setting .....              | 9  |
| 4.4.2 IR Setting.....                  | 11 |
| 4.4.3 TCP/IP Setting.....              | 14 |
| 4.4.4 Delay setting.....               | 15 |
| 4.4.5 Compare Setting.....             | 16 |
| 4.4.6 LED setting .....                | 17 |
| 4.4.7 Toggle Setting.....              | 18 |
| 4.5 Event List.....                    | 20 |
| 5. Specification .....                 | 21 |
| 6. Panel Drawing .....                 | 22 |
| 7. Troubleshooting & Maintenance ..... | 23 |
| 8. After-Sales.....                    | 24 |
| 9. Warranty.....                       | 25 |

# 1. Introduction

## 1.1 Introduction to ALF-IP6

The Alfatron ALF-IP6 Wallplate Control Panel has three built-in programmable RS232 connectors and two Infrared (IR) connectors.

The Programmable Control Panel can fully control the compatible switches, as well as third-party devices such as a matrix switcher, compact scaler switcher, projectors, screens, etc. Use the device for presentations in showrooms, classrooms, and boardrooms.

## 1.2 Features


- Each button can be programmed to send bi-direction RS232 commands simultaneously to control third party devices.
- Each button can be programmed to send the IR codes simultaneously to control the third-party devices and support IR code learning function.
- The unit may be programmed through the Ethernet port, via the Control Software.
- Crystal and backlit buttons with easy user-friendly customizable changeable labels.
- The backlit brightness is controllable.
- Dimension: 70mm long and 41mm wide.

## 1.3 Package List

- 1 x ALF-IP6
- 1 x Power adapter (12VDC 1A)
- 1 x 3-Pin Pluggable terminal block
- 1 x Button label
- 1 x User Manual
- 2 x Screw (M4\*35)
- 3 x 2-Pin Pluggable terminal blocks
- 1 x 5-Pin Pluggable terminal block
- 6 x Button caps

**Note:** Please confirm if the product and the accessories are all included, if not, please contact your local agent.

## 2. Panel Description




| No. | Name      | Description  |
|-----|-----------|--|
| 1   | Power LED | Illuminates red when powered on.   |
| 2   | Button    | <p>Six crystal and luminescent programmable buttons:</p> <p>Each button can be programmed with the Control Panel Software.</p> <p>Each label within a button can be easily changed. Simply select the label you need and change it as shown below:</p> |

|   |                     |  |
|---|---------------------|--|
| 3 | ETHERNET            | RJ45 connector. Connects with a PC to run the Control Panel Software to customize button control. After setting button functions, the port can be connected to a third-party device to control it via buttons. |
| 4 | IR Sensor           | Receives and learns the IR code to build the IR database.  |
| 5 | RS232(1) ~ RS232(3) | Total of three RS232 ports. Connect to third-party devices which need to be controlled via the Control Panel Software.   |
| 6 | PWR (12V)           | Connects with 12V DC power adaptor.  |
| 7 | IR (1) ~ IR (2)     | Two IR output ports. Connects with IR Emitter to control other devices via the Control Panel Software.   |
| 8 | FIRMWARE            | Micro USB port for firmware updating.  |
| 9 | RESET               | Long-press this button for three (3) seconds until the power LED goes out to restore factory default. When the LED lights up, the reset is successful.   |

### 3. System Connection

The ALF-IP6 can activate different ports at the same time. This means every button can send RS232 commands, IP and IR codes at the same time.

The system diagram as below:



- 1) Connect the ALF-IP6 to the LAN port of a Wireless Router or control device (PC) to the ETHERNET port.
- 2) Connect the third-party device (Matrix Switches, Compact Scaler Switches, or a Projector) that need to be controlled to the RS232 (1) ~ RS232 (3) ports.
- 3) Connect the IR Emitters to IR (1) ~ IR (2) ports.




## 4. Control Panel Software

### 4.1 Basic Setting

You can use Control Panel Software to easily set functions for each button.

- 1) Connect the control PC to the ETHERNET port.
- 2) The default IP of the ALF-IP6 wallplate is 192.168.0.178 (modifiable); the control PC should have its network segment the same as the ALF-IP6's.



### Modify the IP of the PC


- 3) Install / uninstall Control Panel Software:
  - Install: Copy the software file to the computer connected with ALF-IP6
  - Uninstall: Delete all the software files in corresponding file path.

4) Double-click the below software icon to run this software:



The main window of the Control Panel Software has five parts:  
Panel Set, TCP/IP, Action List, Event Set and Event List.

The main window of the Control Panel Software is shown as below:



The screenshot shows the main window of the Control Panel Software, divided into five sections with callout boxes:

- Panel Set:** A callout box says "Panel Set: Click '1~6' to set key action". The interface shows six buttons labeled 1 through 6, and input fields for IP Address, Net Mask, Gateway, and Port.
- TCP/IP:** A callout box says "Show IP addresses of all connected devices in LAN.". The interface shows a table with columns "Num" and "Data".
- Action List:** A callout box says "Show all key actions, and any action can be selected for setting events.". The interface shows a table with columns "Key", "Type", and "Data".
- Event Set:** A callout box says "Set events for the selected action.". The interface shows a configuration panel for RS232, IR, TCP/IP, Delay, Compare, LED, and Toggle. It includes fields for Lib name, Lib Function, Port, Baud Rate, Data Bit, Stop Bit, Format (ASCII/HEX), and End Char for ASCII.
- Event List:** A callout box says "Show all events.". The interface shows a table with columns "Num", "Type", and "Data".

The status bar at the bottom of the window displays: 2016/12/23, TCP Status: Disconnected, UDP Status: Activated, Local IP : 192.168.13.17, and <http://www.putron.com>.

The header of the main window has four titles including File, System, Connection, and Help.

- Click “File” → “Save” to save the current setting.
- Click “File” → “Save as” to save all configuration information as a file.
- Click “File” → “Open” to recall a configuration file.
- Click “System” → “Version” to query the current software version.
- Click “System” → “Message” to query the Link Status, Machine Type, Software Version, IP Information, and MAC address.
- Click “File” → “Software Update”

Hold down the “3” button and power on the system until the button lights up to enable update mode → Open upgrade Web page (<http://192.168.0.178:4001/>) on IE → Type User ID (admin) and Password (123456) → upload update file → Click “Upload”

- Click “System” → “Factory Defaults” to restore to factory default.
- Click “Connection” → “TCP/IP” → “Reconnect” to reconnect all ALF-IP6’s.
- Click “Connection” → “Upload” → to load the MCU information from the selected ALF-IP6 to the control software.
- Click “Connection” → “Download” → to download the current setting information to the selected ALF-IP6 from the control software.

## 4.2 Panel Set

Total of six customizable buttons on the front panel can be set via this software. Add a button action to show the action list, then add events to ensure this action will execute the events.

How to set up a button example:

### Panel Set

|   |   |
|---|---|
| 1 | 2 |
| 3 | 4 |
| 5 | 6 |

IP Address:

Net Mask:


Gateway:

Port:

Buttons 1 through 6, correspond to the physical buttons on ALF-IP6. Click on button 1, the following dialog window will pop up:

Key Type:  
1. Press: Execute events when button is pressed.  
2. Release: Execute events when button is released.  
3. Toggle: The button can be regarded as composite key, press the button twice to execute different events.

Built key group for LED setting.



### 4.3 Action List

All Panel Set actions will be shown on the action list and available actions must be added to the list. The action list is as the picture below:

**Action List**

Empty all actions.

| Key | Type | Data   |
|-----|------|--------|
| 1   | Key1 | Press  |
| 2   | Key2 | Press  |
| 3   | Key3 | Toggle |

Delete the selected action.

Delete all invalid actions.

## 4.4 Event setting

Event Set window includes RS232, IR, TCP/IP, Delay, Compare, LED, and Toggle settings. Before setting events, an action must be added first. The following introduction is about how to set events for each action.

### 4.4.1 RS232 Setting

This item is used for setting the events for RS232 (1) ~ RS232 (3) ports. Click “RS232”, it will show as below:


The screenshot shows the 'Event Set' window with the 'RS232' tab selected. On the left, a list of event types includes RS232, IR, TCP/IP, Delay, Compare, LED, and Toggle. The main panel has tabs for RS232, IR, TCP/IP, Delay, Compare, LED, and Toggle. The RS232 settings are as follows:

- Lib name: [Text Input]
- Lib Function: [Dropdown]
- Port: Port1 [Dropdown]
- Baud Rate: 9600 [Dropdown]
- Data Bit: 8 [Dropdown]
- Stop Bit: 1 [Dropdown]
- Parity: None [Dropdown]
- Format:  ASCII  HEX
- End Char for ASCII: NULL [Dropdown]
- Change Lib [Button]
- Edit Lib [Button]
- Delay Send: None [Dropdown]
- Data: [Text Input]
- Clear [Button]
- Add [Button]

#### Operation procedure:


- 1) Select the button action in action list.
- 2) Set the “Lib name” and “Lib Function”. This is an optional function, not compulsory.
- 3) Select the RS232 port. The port must be same as model setting, otherwise the event cannot be added.
- 4) Confirm and set the baud rate, data bit, stop bit, and parity.
- 5) Enter RS232 command in data box, then press “add” to save setting.

- 6) The RS232 data also can be selected from the library. Click “Change Lib” to select a library file and open it, or, click “Edit Lib” to create a library file as below:



**Note:** Once set up, please press “Save” to save the edit or “Save as” to save as a file, and then press “OK”.

- 7) There are two “Delay Send”: Set and None. When selecting “Set”, the number of sending strings and the delay time between strings can be set.



#### 4.4.2 IR Setting

This item is used for setting the events for IR (1) ~ IR (2) ports. Click "IR", it will display as follows:

**Event Set**

RS232 IR TCP/IP Delay Compare LED Toggle

Lib name:  Delay Send:

Lib Function:  Send no.of transmission strings


Port:

Carrier:  Delay time between string



**Operation procedure:**

- 1) Select the button action in action list.
- 2) Set the “Lib name” and “Lib Function”. It is an optional function, not compulsory.
- 3) Select the IR port. The port must be the same as the model setting, or the event cannot be added.
- 4) Set the IR carrier mode: On/Off
- 5) The IR data needs to be selected from library. Click “Change Lib” to select a library file and open it. Click “Edit Lib” to create or edit a library file as below:



**IR Learning Procedure:**

1. Click “learn” to enter IR learning mode.
2. Put the IR Remote close to the IR sensor of the ALF-IP6.
3. Press any button on the IR Remote to send the IR code to the IR sensor, it will then refresh the IR data.
4. Following the above steps enables the device to learn any function of the remote buttons.

**Note:** The IR learning mode will be exited automatically if there is no operation within 3 seconds.

**Note:** Once set up, please press “Save Edit” to save the edit or “Save as” to save as a file, and then press “OK”.

- 6) There are two "Delay Send": Set and None. When selecting "Set", the number of sending strings and the delay time between strings can be set.

**Event Set**

RS232 IR TCP/IP Delay Compare LED Toggle

Lib name:  Delay Send:

Lib Function:

Port:

Carrier:


Send no. of transmission strings

Delay time between string

### 4.4.3 TCP/IP Setting

The TCP/IP port supports pass-through function. You can set the events for different IP port via commands.

**Event Set**



RS232 IR TCP/IP Delay

Type the IP address of the device that needs to be set.

IP:

Port:

Format:  ASCII  HEX

End Char for ASCII:

Data:

Clear

Add

Type in the control command.

#### 4.4.4 Delay setting

This item is to add a delay between two events; when one event is completed, it will delay a certain time then start the next event. The delay setting is as picture below:

**Event Set**

- RS232
- IR
- TCP/IP
- Delay**
- Compare
- LED
- Toggle

RS232 IR TCP/IP **Delay** Compare LED Toggle

Hour:

Minute:

Second:

Reset

Hour: 0~24  
Minute: 0~60  
Second: 0~60

#### 4.4.5 Compare Setting

This item is used for comparing the feedback of the RS232 commands. When the ALF-IP6 sends an RS232 command to the controlled device, the device will send feedback. If the correct feedback is added in the data, the ALF-IP6 will compare it with the feedback received from controlled device, to verify whether the command is working or not. The “Compare” setting is as below:

**Event Set**

RS232 IR TCP/IP Delay **Compare** LED Toggle

Port: Port1

Format:  ASCII  HEX

End Char for ASCII: NULL

Data: [Text Box]

Clear

Add


Enter the compare commands, DO NOT miss any characters.

#### Operation procedure:

- 1) Select the button action in the action list.
- 2) Select the RS232 port. The port must be same as the model setting, or the event cannot be added.
- 3) Set the command format ASCII or Hex, if selecting ASCII then the end character must be set.
- 4) Enter the RS232 command which needs to be compared in data box, then press “add” to save the setting.
- 5) Add an event that the LED lights up to indicate the comparative result.
- 6) For events in one event list, a priority is followed, from top to bottom, so that the compare function can be used in action which has three or more events.

#### 4.4.6 LED setting

This item is used for setting the button LEDs in ALF-IP6 to turn on or off. The setting is as follows:



The screenshot shows the 'Event Set' configuration window. On the left, a list of event types includes RS232, IR, TCP/IP, Delay, Compare, LED (highlighted in blue), and Toggle. The main configuration area has tabs for RS232, IR, TCP/IP, Delay, Compare, LED (selected), and Toggle. Under the LED tab, there are two dropdown menus: 'Key:' set to 'Key1' and 'Light Action:' set to 'On'. A callout box points to the 'Light Action:' dropdown with the following instructions:

1. On: Turn on the LED of button 1
2. Off: Turn off the LED of button 1
3. On/Other Off: Turn on the LED of button 1 and turn off the others.
4. On/Group Off: Turn on the LED of button 1 and turn off the others in same group.







- 3) Press the Button 1, event Num 2 will be executed, press Button 1 again, and the event of Num 4 will be executed.

### 4.5 Event List

The event list shows all events of the selected action. The executing priority abides by the Num order, as displayed below. If there is an event executed incorrectly, all the events that follow it will not be executed.


The screenshot shows the 'Event List' interface. At the top left, there is a title 'Event List'. Below the title are three buttons: a red 'X' button, an up arrow button, and a down arrow button. To the right of these is a 'Clear All' button. Below the buttons is a table with four columns: 'Num', 'Type', and 'Data'. The table contains four rows of data. Callout boxes with green borders and arrows point to the buttons: 'Delete the selected event.' points to the red 'X' button, 'Adjust the execution order for events.' points to the up and down arrow buttons, and 'Clear all events.' points to the 'Clear All' button.

| Num | Type   | Data   |
|-----|--------|--|
| 1   | Toggle | Key1,Toggle Start No.1                                   |
| 2   | RS232  | Lib name:123 Function:Open Port:1,9600bps 8 1,Send No... |
| 3   | Toggle | Key1,Toggle Start No.2                                   |
| 4   | RS232  | Lib name:456 Function:Open Port:1,9600bps 8 1,Send No... |

## 5. Specification

|                         |  |
|-------------------------|--|
| Program Port            | TCP/IP   |
| Output Port             | 3 x RS232, 2 x IR  |
| Output Connector        | 3 x 3-Pin Pluggable terminal blocks,<br>2 x 2-Pin Pluggable terminal blocks, |
| Baud Rate and Protocol  | 9600 baud, 8 data bits, 1 stop bit, no parity                                |
| Software                | ALF-IP6  |
| Power Consumption       | 1W (Max)   |
| Operation Temperature   | 0 ~ +40°C  |
| Storage Temperature     | -10 ~ +55°C  |
| Relative Humidity       | 10% ~ 90%  |
| Power Supply            | Input: 100VAC~240VAC, 50/60 Hz;<br>Output: 12VDC                             |
| Net Weight              | 150g   |
| Case Dimensions (W*H*D) | 70mm x 114mm x 41mm  |

## 6. Panel Drawing



## 7. Troubleshooting & Maintenance

- 1) Should the ALF-IP6 not power up, please check, and ensure the power cord is well connected; the power connections cannot be mixed or incorrectly connected. Then restart the device, should the error persist, the ALF-IP6 may be defective. Please send it to the dealer for repair.
- 2) If connection is unsuccessful, please ensure the network segment of the control PC and the ALF-IP6 is the same.
- 3) When the LED of a button does not light up, please check if there is a compare event in this button. If yes, delete the 'compare' and try again. Should the error persist, the LED may be damaged. Please send the unit to the dealer for repair.
- 4) When serial commands are sent without the functions being executed, please check the baud rate, and make sure it is correct and that the serial connection is well connected.

**Remarks:** For further assistance or solutions, please contact your local distributor.

## After-sales Service

Should you experience problems using the Alfatron ALF-IP6 please refer to the Troubleshooting and Maintenance (7) section. Should the error persist, note that any transport costs of the equipment to the distributor are borne by the user during the warranty.

**Product Limited Warranty:** Alfatron warrants that its products will be free from defects in materials and workmanship for **seven years**, which starts from the first day of purchase.

Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the unit is within the warranty period must be presented to obtain warranty service.

### **What the warranty does not cover (servicing is available at a fee):**

- Warranty expiration.
- Factory applied serial number has been altered or removed from the product.
- Damage, deterioration, or malfunction caused by:
  - Normal wear and tear.
  - Use of supplies or parts not meeting product specifications.
  - No certificate or invoice as the proof of warranty.
- The product model showed on the warranty card does not match with the product or if the product had been altered.
- Damage caused by force majeure.
- Servicing not authorized by Alfatron.
- Any other causes which do not relate to a product defect.
- Delivery, installation or labour charges for installation or setup of the product.

**Technical Support:** Contact our after-sales department at [www.alfatronelectronics.com](http://www.alfatronelectronics.com)

## Warranty

1.1 This limited warranty covers defects in materials and workmanship in this product.

1.2 Should warranty service be required, proof of purchase must be presented to the Company. The serial number on the product must be clearly visible and not have been tampered with in any way whatsoever.

1.3 This limited warranty does not cover any damage, deterioration or malfunction resulting from any alteration, modification, improper or unreasonable use or maintenance, misuse, abuse, accident, neglect, exposure to excess moisture, fire, improper packing, and shipping (such claims must be presented to the carrier), lightning, power surges, or other acts of nature. This limited warranty does not cover any damage, deterioration or malfunction resulting from the installation or removal of this product from any installation, any unauthorized tampering with this product, any repairs attempted by anyone unauthorized by the Company to make such repairs, or any other cause which does not relate directly to a defect in materials and/or workmanship of this product. This limited warranty does not cover equipment enclosures, cables or accessories used in conjunction with this product.

This limited warranty does not cover the cost of normal maintenance. Failure of the product due to insufficient or improper maintenance is not covered.

1.4 The Company does not warrant that the product covered hereby, including, without limitation, the technology and/or integrated circuit(s) included in the product, will not become obsolete or that such items are or will remain compatible with any other product or technology with which the product may be used.

1.5 Only the original purchaser of this product is covered under this limited warranty. This limited warranty is not transferable to subsequent purchasers or owners of this product.

1.6 Unless otherwise specified, the goods are warranted in accordance with the manufacturer's product specific warranties against any defect attributable to faulty workmanship or materials, fair wear and tear being excluded.

1.7 This limited warranty only covers the cost of faulty goods and does not include the cost of labor and travel to return the goods to the Company's premises.

1.8 In the event of any improper maintenance, repair or service being carried out by any third persons during the warranty period without the Company's written authorization, the limited warranty shall be void.

1.9 A 7 (seven) year limited warranty is given on the aforesaid product were used correctly according to the Company's instructions, and only with the use of the Company's components.

1.10 The Company will, at its sole option, provide one of the following three

remedies to whatever extent it shall deem necessary to satisfy a proper claim under this limited warranty:

1.10.1 Elect to repair or facilitate the repair of any defective parts within a reasonable period of time, free of any charge for the necessary parts and labor to complete the repair and restore this product to its proper operating condition.; or

1.10.2 Replace this product with a direct replacement or with a similar product deemed by the Company to perform substantially the same function as the original product; or

1.10.3 Issue a refund of the original purchase price less depreciation to be determined based on the age of the product at the time remedy is sought under this limited warranty.

1.11 The Company is not obligated to provide the Customer with a substitute unit during the limited warranty period or at any time thereafter.

1.12 If this product is returned to the Company this product must be insured during shipment, with the insurance and shipping charges prepaid by the Customer. If this product is returned uninsured, the Customer assumes all risks of loss or damage during shipment. The Company will not be responsible for any costs related to the removal or re-installation of this product from or into any installation. The Company will not be responsible for any costs related to any setting up this product, any adjustment of user controls or any programming required for a specific installation of this product.

1.13 Please be aware that the Company's products and components have not been tested with competitor's products and therefore the Company cannot warrant products and/or components used in conjunction with competitor's products.

1.14 The appropriateness of the goods for the purpose intended is only warranted to the extent that the goods are used in accordance with the Company's installation, classification, and usage instructions.

1.15 Any claim by the Customer which is based on any defect in the quality or condition of the goods or their failure to correspond with specification shall be notified in writing to the Company within 7 days of delivery or (where the defect or failure was not apparent on reasonable inspection by the Customer) within a reasonable time after discovery of the defect or failure, but, in any event, within 6 months of delivery.

1.16 If delivery is not refused, and the Customer does not notify the Company accordingly, the Customer may not reject the goods and the Company shall have no liability and the Customer shall pay the price as if the goods had been delivered in accordance with the Agreement.

1.17 THE MAXIMUM LIABILITY OF THE COMPANY UNDER THIS LIMITED

WARRANTY SHALL NOT EXCEED THE ACTUAL PURCHASE PRICE PAID FOR  
THE PRODUCT